



Make Every Moment Count!®

GETTING STARTED WITH YOUR TIME TIMER® MOD ACCESSORIES

Congratulations on the purchase of your new Time Timer® MOD accessory. We hope that it helps you make every moment count!



1

REPLACING A SILICONE CASE

A durable and attractive way to protect your new MOD. The silicone cases are soft and flexible.



REMOVE CURRENT CASE

If your MOD currently has a silicone case, gently peel back the case to remove.



2

REPLACE SILICONE CASE

Gently place the MOD in the silicone case making sure to pull all edges around the front lip of the MOD.

Whenever you want a change of pace, it's easy to switch the color of your Time Timer MOD®. It's available in our most popular colors! Silicone cases are sold separately.

1

USING THE MAGNETIC DRY ERASE BOARD

Add your schedule with a dry erase marker or use a magnet to hold important messages!



INSTALL ONE AA BATTERY

The battery cover is located on the back of the MOD. You may need to remove your MOD from the Dry Erase Accessory by gently pushing on the product from the back. Once removed, simply lift battery cover up from the bottom edge to insert AA battery into compartment. Close battery compartment by pressing closed until you hear a "click".



2

INSERT YOUR MOD*

*Please note that the Time Timer® MOD must include a silicone case to fit correctly in the Dry Erase Board.

Add your MOD to the Dry Erase Accessory by inserting it into the cutout provided on the Dry Erase Accessory. Gently push all corners of the MOD until flush with the Dry Erase Board surface.



QUESTIONS? WE'RE HERE TO HELP: SUPPORT@TIMETIMER.COM